

33=3/4" STAINLESS STEEL SCREWS

PLACE EACH PART IN PLACE
THEN DRILL 5/32" HOLES FOR
EACH PANEL. DRILL WHERE ALL
3/16" HOLES ARE IN EACH PANEL.



YR100
YAMAHA RHINO 450-700 06-09



REMOVE STOCK
PANEL TO INSTALL
THE NEW ALUM.
PANEL. →

REMOVE ANY TIE HOOKS ARE OTHER PROTRUDING
BOLTS THAT ARE IN THE BED PANELS. MOUNT THE NEW
ALUM. PANELS AND REINSTALL ALL HARDWARE THAT
WAS REMOVED.