

4=1/4 X 1/2 U-BOLTS
8=1/4 LOCK NUTS
8=1/4 USS WASHERS
4=1 1/2 PLUGS USED TO PRESS
INTO THE ENDS OF THE PIPES.



#BG-39

KAWASAKI BRUTE FORCE 750 2012



PLACE THE U-BOLT OVER THE TUBE OF THE FRONT RACK AND ALSO THE BOTTOM MOUNT WILL BE THE SAME WAY. USE THE 1/4 WASHERS AND LOCK NUTS TO SECURE THE BUMPER TO THE STOCK BUMPER. THIS PICTURE IS ONLY TO REPRESENT HOW THE U-BOLTS WILL BE USED. PICTURE MAY NOT LOOK THE SAME AS YOUR MACHINE.