

2=5/16 X 1/2 U-BOLTS
2=5/16 X 1 BOLTS
14=5/16 USS WASHERS
12=5/16 LOCKNUTS
10=5/16 X 1 PAINTED CARRIAGE HEAD BOLTS

THE WINCH WILL COME WITH ITS OWN MOUNTING HARDWARE AND ROLLER MOUNT PLATE.

MOUNT THE TOP OF THE MAIN MOUNTING BRACKET USING U BOLTS WASHERS AND LOCK NUTS. PLACE ROD CAPS OVER THE EXISTING THREADS AFTER TIGHTENING HARDWARE.

SECURE THE BOTTOM OF THE MOUNT WITH THE TWO 5/16 X 1 BOLTS FOUR 5/16 USS WASHERS AND TWO LOCK NUTS.

SLIDE THE MAIN BUMPER OVER THE MOUNTING BRACKET USE SIX OF THE CARRIAGE HEAD BOLTS WASHERS AND LOCK NUTS.

MOUNT THE TOP BAR ONTO THE BUMPER USING FOUR PAINTED CARRIAGE HEAD BOLTS WITH USS WASHERS AND LOCK NUTS.

**AFTER THE BUMPER HAS BEEN MOUNTED
PLAY CLOSE ATTENTION WHEN LOADING THE
ATV IN BACK OF TRUCK BEDS.**



BG-46

HONDA FOREMAN 500 2014
AND RANCHER 420 2014

