

2=5/16 X 3/4 U-BOLTS  
2=5/16 X 1 BOLTS  
16=5/16 USS WASHERS  
16=5/16 LOCKNUTS  
10=5/16 X 1 PAINTED CARRIAGE HEAD  
BOLTS  
4=5/16 ROD CAPS

THE WINCH WILL COME WITH ITS OWN  
MOUNTING HARDWARE AND ROLLER  
MOUNT PLATE.



# # BG-47W

HONDA RUBICON 500 2015

MOUNT THE TOP OF THE MAIN  
MOUNTING BRACKET USING U BOLTS  
WASHERS AND LOCK NUTS. PLACE  
ROD CAPS OVER THE EXISTING  
THREADS AFTER TIGHTENING  
HARDWARE.



SECURE THE BOTTOM OF THE  
MOUNT WITH THE TWO 5/16  
X 1 BOLTS FOUR 5/16 USS  
WASHERS AND TWO LOCK  
NUTS.



SLIDE THE MAIN BUMPER  
OVER THE MOUNTING  
BRACKET USE SIX OF THE  
CARRIAGE HEAD BOLTS  
WASHERS AND LOCK NUTS.

MOUNT THE TOP BAR ONTO  
THE BUMPER USING FOUR  
PAINTED CARRIAGE HEAD  
BOLTS WITH USS WASHERS AND  
LOCK NUTS.

**AFTER THE BUMPER HAS BEEN MOUNTED  
PLAY CLOSE ATTENTION WHEN LOADING THE  
ATV IN BACK OF TRUCK BEDS.**

