

10=1/4X1/2 U-BOLTS-A
20=1/4 LOCK NUTS-B
20=1/4 SAE WASHERS-C
4=1 1/2" PLUGS-D
16=1/4 ROD CAPS



PLACE THE 1/4 ROD CAPS ON ALL EXISTING THREADS THAT ARE LEFT AFTER INSTALLING THE RBG-16.

RBG -16

HONDA RANCHER'S REAR BUMPER

THESE U-BOLTS ONCE THEY HAVE BEEN INSTALLED YOU MAY HAVE TO CUT THE EXISTING THREADS OFF WITH A PAIR OF CUTTING PLIERS.

