

6=CARRIAGE HEAD BOLTS
(90185A583)
6=5/16 LOCK NUTS
6=5/16 USS WASHERS
2=1/4 X 1 TORX SCREWS

#RBG-32W

KAWASAKI TERYX 750

REMOVE THE STOCK 8MM NUTS AND PLACE BRACKET INTO POSITION AND SECURE THE BRACKET WITH THE 8MM NUTS THAT WERE REMOVED. THERE WILL BE A RIGHT AND LEFT BRACKET TO INSTALL.



THIS IS THE RIGHT BRACKET LOOKING AT THE REAR OF THE MACHINE.



SCREW THE ALUM. PLATE TO THE BACK/INSIDE OF THE BUMPER. USE THE BLACK SELF THREADING TORX SCREWS FOR THIS MOUNT.



MOUNT THE MAIN BUMPER TO THE BRACKETS USING THE SIX CARRIAGE HEAD BOLTS AND 5/16 USS WASHER WITH THE 5/16 LOCK NUTS.