

- 6=1/4 X 1 BOLTS
- 12=1/4 USS WASHERS
- 6=1/4 LOCK NUTS
- 4=(8694K73) 1" WIDE FOAM TAPE 4 3/4" LONG
- 2=(CTL 354) RUBBER STRAPS 4" LONG
- 2=(3/16) L BRACKETS
- 2=(3/16) U BRACKETS



CT102

ALUM. CAB TOP FOR KAW. MULES
3000/3010/3020 2X4 & 4X4'S

USE ONE OF THE FOUR PIECES OF 1" ADHESIVE TAPE TO PLACE HERE ON TOP OF THE ROLL BAR . REPEAT THE SAME FOR THE OTHER SIDE.

MOUNT THE REAR BRACKETS TO THE ROLL BAR USING THE STOCK BOLTS MUST REMOVE THE LOCK WASHER THAT IS ON THE BOLT.

USE ONE OF THE FOUR PIECES OF 1" ADHESIVE TAPE TO PLACE HERE ON TOP OF THE ROLL BAR . REPEAT THE SAME FOR THE OTHER SIDE.

PLACE THE RUBBER STRAPPING INTO THE U BRACKETS THEN MOUNT TO THE ROLL BAR. REPEAT THE SAME PROCEDURE FOR THE OTHER SIDE ALSO.



THE TOP WILL MOUNT TO THE BRACKETS WITH SUPPLIED 1/4 X 1 BOLTS WASHERS AND LOCK NUTS.

