

STRONG  MADE™


BY SAVANT MANUFACTURING, INC.

www.savantmfg.com

CT103

ALUM. CAB TOP FOR KAW.
MULES 600 610 2X4 & 4X4'S

- 6=1/4 X 1 BOLTS
- 12=1/4 USS WASHERS
- 6=1/4 LOCK NUTS
- 4=(8694K73) FOAM TAPE 4 3/4" LONG
- 2=(1100 B7 X 3/16) RUBBER STRAPS 4" LONG
- 2=(3/16) L BRACKETS
- 2=(3/16) U BRACKETS
- 4=3/16 X 1 WASHERS



USE ONE OF THE FOUR PIECES OF 1" ADHESIVE TAPE TO PLACE HERE ON REAR TOP OF THE ROLL BAR . REPEAT THE SAME FOR THE OTHER SIDE.

USE ONE OF THE FOUR PIECES OF 1" ADHESIVE TAPE TO PLACE HERE ON FRONT TOP OF THE ROLL BAR . REPEAT THE SAME FOR THE OTHER SIDE.



MOUNT THE REAR BRACKETS TO THE REAR OF THE ROLL BAR USING THE STOCK BOLTS. REPEAT THE SAME FOR THE OTHER SIDE.



INSERT THE RUBBER TRIM INTO THE U BRACKETS, THEN MOUNT THE FRONT OF THE TOP TO THE ROLL BARS. THE 3/16 X 1 WASHERS NEED TO BE PLACED IN BETWEEN THE BRACKETS AND THE TOP. USE THE 1/4 X 1 BOLTS 1/4 LOCK NUTS AND THE 1/4 USS WASHERS TO MOUNT THE FRONT AND REAR OF THE TOP TO THE BRACKETS.

