




- 4=5/16 X 1 BOLTS
- 4=5/16 LOCK NUTS
- 8=5/16 USS WASHERS
- 4=(8694K73)16" LONG 1" WIDE

ADHESIVE FOAM TAPE  
 2=SMALL L SHAPED BRACKETS  
 MAKE SURE YOU HAVE A LEFT  
 AND A RIGHT.



# # CT112

KAWASAKI TERYX ALUM. CAB TOP

THEIR WILL BE FOUR 14" SINGLE SIDED  
 ADHESIVE TAPE SUPPLIED. THIS IS TO BE  
 PLACED ONTO THE TOP AND SIDE OF  
 THE ROLL BAR. THE TWO SHORT BENT  
 SIDES OF THE CAB TOP WILL SIT ONTO  
 THESE PIECES OF TAPES.



**FOR THE FRONT MOUNT THE SMALL  
 MOUNTING BRACKETS TO THE FRONT  
 OF THE ROLL BAR. THE BRACKETS WILL  
 USE THE STOCK BOLTS IN THE ROUND  
 HOLES OF THE BRACKETS. THEIR IS A  
 RIGHT AND LEFT BRACKET FOR THE  
 FRONT.**



**FOR THE REAR MOUNT THE TOP TO THE  
 ROLL CAGE THROUGHT THE CLIPS THAT  
 ARE WELDED ON THE REAR SUPPORT  
 BAR OF THE ROLL CAGE.. USE TWO 5/16  
 X 1 BOLTS TWO 5/16 USS WASHERS AND  
 TWO LOCK NUTS.**