

8= 1/4 X 7/8 BOLTS-A

8= 1/4 USS WASHERS-B

8= 1/4 LOCK NUTS

72"= 1" FOAM TAPE

4= BENT CLAMPS (CT114-2-BO'S)

BEFORE INSTALLING THE TOP, CUT THE 1" TAPE INTO 8" PIECES TO PLACE ON TOP ON THE ROLL CAGE.

PLACE ONE OF THE 8" PIECES OF FOAM TAPE ON TOP OF ROLL CAGE ON EACH OF THESE LOCATIONS.

PLACE ONE OF THE 8" PIECES OF FOAM TAPE ON TOP OF ROLL CAGE ON EACH OF THESE LOCATIONS.

PLACE THE TOP ON THE ROLL CAGE. CENTER THE TOP AND PLACE A U CLAMP OVER THE TUB. WHERE EACH SET OF HOLES ARE IN THE TOP. **DO NOT TIGHTEN ANY CLAMP TILL ALL HAVE BEEN PLACED.**



CT114

CAN AM COMMANDER ALUM. CAB TOP

