

- 4=5/16 X 1 U-BOLTS-A
- 20=5/16 LOCK NUTS-B
- 30=5/16 USS WASHERS-C
- 8=5/16 ROD CAPS-D
- 2=5/16 X 3/8" LOCKING PINS-E
- 2=1100 B7X3/16 TRIM LOCK
- 18 1/2" LONG PC'S-F
- 10=5/16 X 1 BOLTS-G
- 2=5/16 X 1 1/4 BOLTS-H



DBB103

DOUBLE BOOT BRACKET FOR
ARCTIC CAT 650 PROWLER H1 4X4.

1st Step

This boot bracket bolts to the two middle bars that looks like a V. These bars are on the back of the roll cage.

2nd Step

90° Bend here.

93° Bend here.

There is a support bracket that is used under the main bracket. Install the bracket as the pic. illustrates.

3rd Step

Mount this small lever arm bracket to the main bracket on this position of the boot bracket.

4th Step

Mount this small lever arm bracket to the boot bracket on this position of the boot bracket.

Mount one of the small lever arms to the this adjustment bracket.

5th Step

Mount one of the small lever arms to the this adjustment bracket.

6th Step

Last Step

This is where the adjustment brackets will bolt to the boot bracket.

Insert the rubber trim into the oval round holes in the boot bracket.