

- 4=5/16 X 1 1/4 U-BOLTS-A
- 18=5/16 LOCK NUTS-B
- 30=5/16 USS WASHERS-C
- 4=5/16 ROD CAPS-D
- 2=5/16 X 1 3/8" LOCKING PINS-E
- 2=1100 B7X3/16 TRIM LOCK
- 18 1/2" LONG PC'S-F
- 8=5/16 X 1 BOLTS-G
- 2=5/16 X 1 1/4 BOLTS-H



DBB104

DOUBLE BOOT BRACKET FOR POLARIS RANGER RZR 800 4X4

1st Step

MOUNT THE BRACKET TO THE ROLL CAGE.

2nd Step

3rd Step

Mount this small lever arm bracket to the main bracket on this position of the boot bracket.

4th Step

Mount this small lever arm bracket to the boot bracket on this position of the boot bracket.

5th Step

Mount one of the small lever arms to the this adjustment bracket.

6th Step

Mount one of the small lever arms to the this adjustment bracket.

Last Step

This is where the adjustment brackets will bolt to the boot bracket.

Insert the rubber trim into the oval round holes in the boot bracket.