

- 6=1/4 USS WASHERS
- 2=6MM X 1 X 25MM BOLTS
- 2=6MM X 1 X 40MM BOLTS
- 2=6MM X 1 X 50MM BOLTS
- 2=7/8" GALV. SPACERS
- 2=11/16" GALV. SPACERS

THIS IS A PIC. OF THE ALUM. GUARD BUT THE MOUNTING OF THE GUARDS ARE THE SAME.



# # FG124-STL

HONDA RANCHER 420

THE GUARD IS TO BE INSTALLED OVER THE ORIGINAL PLASTIC GUARD. DO NOT REMOVE ANY PLASTIC PARTS.

**2ND STEP**

- 2=6MMX1X40MM BOLTS
- 2=1/4 USS WASHERS
- 11/16" SPACERS

**1ST STEP**

- 2=6MMX1X50MM BOLTS
- 2=1/4 USS WASHERS
- 7/8" SPACERS

**LAST STEP**

- 2=6MMX1X25MM BOLTS
- 2=1/4 USS WASHERS
- NO SPACERS

LEAVE ALL BOLTS LOOSE UNTIL ALL THE HARDWARE HAS BEEN INSTALLED IN THE GUARD.

REMOVE ALL STOCK BOLTS TO INSTALL THE FG124-AL.

THE SPACERS ARE USED BETWEEN THE NEW SKID AND THE ORIGINAL PLASTIC SKID.

