

- 4=5/16 X 1 3/4 BOLTS
- 4=5/16 LOCK NUTS
- 4=3/4 SQUARE PLUGS
- 8=5/16 USS WASHERS
- 4=1/4 ROD CAPS
- 2=1/4 X 1 SQUARE U-BOLTS
- 4=1/4 LOCK NUTS
- 4=1/4 USS WASHERS

BEFORE MOUNTING THE BASKET TO THE BRACKETS INSERT THE 3/4 " BLACK SQUARE PLUGS IN THE ENDS OF THE TUBING.

MOUNT THE SIDE BRACKETS TO THE MACHINE USING THE STOCK LOWER BOLTS. TO MOUNT THE TOP OF THE BRACKET USE THE 1/4 X1 U-BOLTS 1/4 USS WASHERS AND 1/4 LOCK NUTS WITH THE 1/4 ROD CAPS TO COVER THE EXISTING THREADS. THERE WILL BE A RIGHT AND LEFT SIDE BRACKET.

MOUNT THE BASKET TO THE BRACKETS USING THE 5/16 X 1 3/4 BOLTS 5/16 USS WASHERS AND 5/16 LOCK NUTS. REPEAT THE SAME PROCESS FOR BOTH SIDES.

THIS IS A VIEW FROM THE UNDERNEATH OF THE BRACKETS AFTER THE BASKET HAS BEEN MOUNTED. USE THE 5/16 USS WASHERS AND 5/16 LOCK NUTS.



# # 240

## RUFF & TUFF HUNTER EDITION

