

**4=1/4 X 1 BUTTON HEAD  
STAINLESS SCREWS**



**CENTER LIGHT IS NOT INCLUDED. THIS CAN BE BOUGHT AT ANY LOCAL WALMART OR AUTO PARTS STORE..**

## **# LK102**

**CENTER LIGHT BRACKET  
CAN AM OUTLANDERS / RENEGADES**

**REMOVE THE PLASTIC HANDLEBAR GUARD BEFORE MOUNTING THE BRACKET. THIS WILL BE REPLACED AFTER THE BRACKET HAS BEEN MOUNTED..**

**REMOVE THE STOCK LOCK NUTS THAT ARE UNDER THE HANDLE BAR MOUNTING PLATE. PLACE THE BRACKET OVER THE STOCK BOLTS. TIGHTEN THE NUTS TO STOCK TORQUE SPECS. THE BRACKET WILL MOUNT UNDER THE HANDLE BAR MOUNT PLATE.**

**MOUNT THE TOP LIGHT PLATE TO THE MAIN BRACKET. USE THE SUPPLIED 1/4 X 1 BUTTON HEAD STAINLESS SCREWS.**

