BY SAVANT MANUFACTURING, INC. www.savantmfg.com

#522

STRONG SMMADE

 $A = 2 = 5/16 \times 2$ Bolts

- B = 2 = 1" Plug
- C = 8 = 5/16 SAE.(Small) Flat Washers
- D = 4 = 5/16 Lock nut
- $E = 4 = 3/16 \times 1 \times 7/8$ OVR Clip (oval slot clip) F = 2 = 5/16 x 3 1/4 Bolts

