by savant manufacturing, inc. www.savantmfg.com

STRONG 5 MADE

B = 4 = $5/16 \times 3$ Bolts C = 8 = 5/16 SAE.(Small) Flat Washers D = 4 = 5/16 Lock nut E = 4 = $3/16 \times 1 \times 7/8$ OVR (oval slot holes)

F = 2 = 1" Plug

#537

SUZUKI KING QUADAND QUAD RUNNER

