



- A - 4= Gr. 8 (gold) 5/16 USS WASHERS
- B - 4=5/16 X 3 1/4 BOLTS
- C - 6=5/16 LOCK NUTS
- D - 2=1" PLUGS
- E - 4=3/16 X 1 ZINC PLATED WASHERS

561

2005 POLARIS SPORTSMAN REAR RACK

TWO OF THESE NUTS WILL BE USED UNDER THE FENDERS ON THE STOCK BOLTS THAT HOLD THE COMPOSITE RACK TO THE UNDER FRAME. THEY ARE USED TO KEEP THE BOLTS FROM PULLING THROUGH THE METAL.

Caution: DO NOT USE AIR TOOLS to install, may result to injury.

