

SP 102

Fits: **HONDA 300 2X4, 4X4 '93-'99**

INSTALLATION

When installing, you must first remove any after market stick stoppers (CV Joint Boot Protectors). One side may do, but for easy installment remove both sides. This allows room for putting the flat plate into position for bolt up of the skid plate to the frame.

After tightening the U-Bolts, cut off the excess U-Bolt showing.

Hardware

- 4 = 5/16 x 1 U Bolt
- 2 = 5/16 x 1 Bolt
- 10 = 5/16 lock Nuts
- 12 = 5/16 small flat Washers
- 1 = Flat Plate 3/18 x 1 x 2 7/8 two Holes

