

4=5/16 SMALL FLAT WASHERS = A
1=5/16 X 1 1/2 BOLTS = B
1=5/16 LOCKNUT = C
1= 225 WASHER 5/16 X 1/2 OVAL HOLE x
3/16 x 1 1/2 = D
2=8MM X 1.25 X 30 BOLTS = E

SMI SAVANT
MFG., INC.

SP106AL HONDA 450S,450ES

**MUST REMOVE THE
FACTORY SKID PLATE
TO INSTALL!!!**

