

6 = 1/4 X 1/2 U-BOLTS
12 = 1/4 SMALL (SAE) WASHERS
12 = 1/4 LOCK NUTS



YOU MUST REMOVE THE PLASTIC
BOOT PROTECTORS TO INSTALL THE
NEW SS122 METAL PROTECTORS!!!!

SS122

HONDA 500 4X4
HONDA 450 4X4
HONDA 400 4X4
HONDA 350 4X4

THE SS122 WILL
BOLT UNDER
THE A ARMS AS
SHOWN HERE..

THIS END WILL
FACE THE INSIDE
OF THE RIM ONCE
MOUNTED.

