6=1/4 X 1/2 U-BOLTS-A 6=1/4 TANNER RIVETS-B 6=5/16 SAE WASHERS-C 12=1/4 LOCK NUTS-D 12=1/4 WASHERS-E

EVEN THOUGH THE NEW BOOT GUARDS YOU HAVE PURCHASED WILL COVER MORE THAN THE ORIGINAL PLASTIC GUARDS. BOOTS HAVE BEEN REPORTED TO BE TORN IN SOME CONDITIONS.DUE TO THE TURING RADIUS ON SOME OF THE NEWER ATV'S. THE BOOT PROTECTORS HAVE BEEN MANUFACTURED SMALLER TO ALLOW FOR A TIGHTER TURING RADIUS. SAVANT MFG. (STRONG MADE) DOES NOT WARRANTY AND TORN BOOTS.



SS149H

HONDA FOREMAN 500 4X4

