

8=1/4X3/4 BOLTS  
8=1/4 LOCK NUTS

**STRONG  MADE™**

BY SAVANT MANUFACTURING, INC.

www.savantmfg.com

**MUST REMOVE ANY  
PLASTIC GUARDS.**

**#SS176H**  
CAN-AM OULANDER 650

INSTALL UNDER THE  
A-ARMS AND PLACE THE  
BENT LIP TOWARDS THE  
INSIDE OF THE RIM.

REMOVE THIS STOCK BOLT  
TO INSTALL THE GUARD.  
REPLACE THE BOLT TO  
SECURE THIS END OF THE  
GUARD TO THE A-ARM

THERE WILL BE TWO  
SMALL PLATES SUPPLIED  
IN THE HARDWARE TO  
SECURE THE REAR OF THE  
GUARD TO THE A-ARM.  
USE FOUR OF THE 1/4 X 3/4  
BOLTS AND 1/4 LOCK NUTS  
HERE.

PLACE THE BOLTS IN  
FROM THE BOTTOM OF  
THE PLATES LEAVING THE  
EXCESS THREADS ON THE  
INSIDE OF THE GUARD.

REPEAT THE SAME STEPS TO INSTALL THE OPPOSITE SIDE.