

4=1/4X7/8 BOLTS
4=1/4 USS WASHERS
4=1/4 LOCK NUTS

REMOVE PLASTIC GUARDS.
THE STOCK HARDWARE WILL BE
REUSED TO MOUNT THE METAL
GUARDS.

MOUNT THE RIGHT SIDE GUARD
BUT DO NOT TIGHTEN THE
BOLTS.

MOUNT THE LEFT SIDE GUARD
BUT DO NOT TIGHTEN THE
BOLTS.

MOUNT THE TWO GUARDS
TOGETHER WITH THE MOUNTING
PLATE THEN TIGHTEN ALL THE
BOLTS.

USE THE HARDWARE HERE
THAT IS SUPPLIED IN THE
BAG.

STRONG  MADETM
BY SAVANT MANUFACTURING, INC.
www.savantmfg.com

SS177H

REAR GUARDS FOR CAN-AM 650 4X4

