

6=1/4 GALV. SPACERS 3/8 LONG -A
6=6MM X 1 X 25MM BOLTS-B

REMOVE PLASTIC GUARDS FOR
INSTALLING THE NEW METAL
GUARDS. MUST REUSE THE
WASHERS ON THE ORIGINAL
STOCK BOLTS.



SS182H

FRONT GUARDS KAWASAKI TERYX 750

