

- 6=1/4 X 3/8 U-BOLTS-A
- 12=1/4 LOCK NUTS-B
- 12=1/4 WASHERS-C
- 6= TANNER RIVITS-D
- 6=5/16 SAE WASHERS-E



SS199H

ARCTIC CAT MUD PRO 700

EVEN THOUGH THE NEW BOOT GUARDS YOU HAVE PURCHASED WILL COVER MORE THAN THE ORIGINAL PLASTIC GUARDS. BOOTS HAVE BEEN REPORTED TO BE TORN IN SOME CONDITIONS .DUE TO THE TURING RADIUS ON SOME OF THE NEWER ATV'S. THE BOOT PROTECTORS HAVE BEEN MANUFACTURED SMALLER TO ALLOW FOR A TIGHTER TURING RADIUS. SAVANT MFG. (STRONG MADE) DOES NOT WARRANTY AND TORN BOOTS.

PLACE THE GUARD INTO PLACE UNDER THE LOWER CONTROL ARM. THIS END WILL FACE THE INSIDE OF THE RIM ONCE MOUNTED.

INSERT THE PINS WITH THE 5/16 SAE WASHERS INTO THE GUARDS BEFORE PLACING UNDER THE ARM.

INSERT THE U-BOLTS OVER THE TUB. TO MOUNT THE GUARDS TO THE ARM.

SECURE THE GUARD WITH THE 1/4 SAE WASHERS AND 1/4 LOCK NUTS.

REPEAT THE SAME PROCEDURE FOR THE OPPOSITE SIDE.

THE SS199H WILL BOLT UNDER OF THE A- ARMS. MUST REMOVE THE PLASTIC GUARDS FIRST.

