

- 8=1/4 X 1/2 U-BOLTS-A
- 16=1/4 LOCK NUTS-B
- 16=1/4 SAE WASHERS-C
- 8=5/16 SAE WASHERS-D
- 8=#16 TANNER RIVETS-E



SS200H

REAR GUARDS ARCTIC CAT 700
MUD PRO...

**MUST REMOVE THE
PLASTIC GUARDS BEFORE
INSTALLING THE METAL
GUARDS.**

PLACE THE RIVETS WITH THE
5/16 SAE WASHERS INTO THE
MIDDLE U-BOLT HOLES. PLACE
THE GUARD UNDER THE
LOWER CONTROL ARM. INSERT
THE U-BOLTS OVER THE ROUND
TUB. AND SECURE THE GUARD
WITH THE 1/4 WASHERS AND
LOCK NUTS.

SECURE THE GUARD TO THE
TUB. WITH THE 1/4 SAE
WASHERS AND 1/4 LOCK NUTS.

THIS IS A PIC. OF THE GUARD
ONCE IT HAS BEEN MOUNTED
UNDER THE LOWER CONTROL
ARM. REPEAT THE SAME
PROCEDURE FOR THE OPPOSITE
SIDE.

