

SS109

CAUTION

DO NOT OVER TIGHTEN U-BOLTS !
May brake bolts or may bend boot protector (Torque no more than 5 foot Lbs). If you bend the boot protector they may rub or tear the CV Boots.
After installing the boot protecters: turn the tires left to right, check the rims and CV boots for any type of rubbing.

- 4 = 1/4 x 2 1/4 bolts = A
- 4 = 1/4 x 2 bolts = B
- 8 = 1/4 locknuts
- 16 = 1/4 Flat Washers
- 2 = 1/4 X 1 X 4 13/16 Flat Bar 2 holes
- 2 = 1/4 x 1 1/2 x 9 5/16 Flat Bar 2 holes

