

# SS 113

- 12 = 1/4 Lock Nuts  
12 = 1/4 Small Flat Washes (SAE)  
2 = 1/4 x 3/8 U-Bolts (B)  
4 = 1/4 x 1/2 U-Bolts (A)

- 1 = Pair of SS113 (Right and a Left)

Yamaha Wolverine  
CV boot protectors

### CAUTION

DO NOT OVER TIGHTEN U-BOLTS !  
May brake U-bolts or may bend boot protector (Torque no more than 5 foot Lbs). If you bend the boot protector they may rub or tear the CV Boots.  
After installing the boot protectors: turn the tires left to right, check the rims and CV boots for any type of rubbing.

