

- 2 = 1/4 x 2 Bolts
- 4 = 1/4 x 3/4 U Bolts
- 10 = 1/4 Lock Washers
- 10 = 1/4 Nuts
- 12 = 1/4 Flat Washers



EVEN THOUGH THE NEW BOOT GUARDS YOU HAVE PURCHASED WILL COVER MORE THAN THE ORIGINAL PLASTIC GUARDS. BOOTS HAVE BEEN REPORTED TO BE TORN IN SOME CONDITIONS .DUE TO THE TURNING RADIUS ON SOME OF THE NEWER ATV'S. THE BOOT PROTECTORS HAVE BEEN MANUFACTURED SMALLER TO ALLOW FOR A TIGHTER TURNING RADIUS. SAVANT MFG. (STRONG MADE) DOES NOT WARRANTY AND TORN BOOTS

SS121

Rear CV Boot Protection
for the Arctic-Cat 300 2x4
and 4x4

