

STRONG SM MADE™

BY SAVANT MANUFACTURING, INC.

www.savantmfg.com

**4=5/16X1 BOLTS
4=5/16 LOCK NUTS
8=5/16 SAE WASHERS**

IF THE WARN RT25 IS USED MUST USE THE METRIC BOLTS THAT ARE SUPPLIED WITH THE HARDWARE IN THE BAG WITH THE WINCH. THESE BOLTS ARE USED TO MOUNT THE WINCH TO THE PLATE.

IF THE HAWSE FAIRLEAD FROM WARN IS USED IN PLACE OF THE ROLLER FAIRLEAD USE THE BOLTS AND NUTS THAT OR ON THE HAWSE.

THIS PLATE IS DESIGNED TO FIT THE RAMSEY 2500LB AND ALSO THE WARN 2000LB , 2500LB WINCHES.

RAMSEY'S WINCH IS SUPPLIED WITH A ROLLER FAIRLEAD. THE WARN WILL COME WITH A HAWSE FAIRLEAD. THIS DEPENDS ON THE WINCH THAT IS PURCHASED. BOTH THE ROLLER OR HAWSE FAIRLEAD WILL MOUNT IN THAT SPECIFIC POSITION.

298031-R59

SUZUKI VINSON 500 4X4 2002



STEP 1: REMOVE THE PLASTIC FRONT FRAME COVER BY REMOVING THE TWO LOWER MOUNTING BOLTS AND TWO UPPER PUSH CLIPS.

STEP 2: USING THE FOUR 5/16X1 BOLTS , WASHERS AND LOCK NUTS THAT ARE SUPPLIED AT THE TOP OF THE PAGE MOUNT THE PLATE TO THE FRAME .

STEP 3: MOUNT THE FAIRLEAD TO THE PART OF THE PLATE THAT IS BENT UP IN THE FRONT THE HARDWARE FOR THIS AND ALSO TO MOUNT THE WINCH IS IS INCLUDED IN THE WINCH .

SAVANT'S MFG PH. # 1-800-326-6880

EMAIL ADDRESS www.savantmfg.com