

USE THE HARDWARE THAT COMES WITH THE WINCH TO MOUNT THE PLATE TO THE ATV.

IF THE HAWSE FAIRLEAD FROM WARN IS USED IN PLACE OF THE ROLLER FAIRLEAD USE THE BOLTS AND NUTS THAT OR ON THE HAWS.

IF THE WARN RT25 IS USED MUST USE THE METRIC BOLTS THAT ARE SUPPLIED WITH THE HARDWARE IN THE BAG WITH THE WINCH. THESE BOLTS ARE USED TO MOUNT THE WINCH TO THE PLATE.

REMOVE THE FRONT TWO BOLTS THAT ARE HOLDING THE PLASTIC SKID PLATE TO BE ABLE TO DROP THE FRONT OF THE PLASTIC.

PLACE THE WINCH INTO THE FRAME FIRST THIS WILL BE A LITTLE DIFFICULT BUT IT WILL FIT THEN SLIDE THE PLATE ON TOP OF THE TABS THAT ARE WELDED TO THE BUMPER, (ON SOME OF THE NEWER BIKES THE PLATE MAY HAVE TO BE PLACED UNDER THE TABS) PLACE THE PLATE AND RUN THE BOLTS AND WASHERS THROUGH THE TAB HOLES INTO THE PLATE SCREWING INTO THE WINCH. THEN PROCEED TO MOUNT THE ROLLER FAIRLEAD.



THIS PLATE IS DESIGNED TO FIT THE RAMSEY 2500LB, AND ALSO THE WARN 2000LB , 2500LB WINCHES.

RAMSEY'S WINCH IS SUPPLIED WITH A ROLLER FAIRLEAD. THE WARN WILL COME WITH A HAWSE FAIRLEAD. THIS DEPENDS ON THE WINCH THAT IS PURCHASED. BOTH THE ROLLER OR HAWS FAIRLEAD WILL MOUNT IN THAT SPECIFIC POSITION.

298049-R68

2003 YAMAHA KODIAK 450 4X4



SAVANT'S MFG PH. # 1-800-326-6880

EMAIL ADDRESS www.savantmfg.com