



THIS PLATE IS DESIGNED TO FIT THE RAMSEY 2500LB, AND ALSO THE WARN 2000LB , 2500LB WINCHES.

RAMSEY'S WINCH IS SUPPLIED WITH A ROLLER FAIRLEAD. THE WARN WILL COME WITH A HAWSE FAIRLEAD. THIS DEPENDS ON THE WINCH THAT IS PURCHASED. BOTH THE ROLLER OR HAUS FAIRLEAD WILL MOUNT IN THAT SPECIFIC POSITION.

- 2=1/4 X 3/4 U-BOLTS**
- 4=1/4 LOCK NUTS**
- 4=1/4 USS WASHERS**
- 6=5/16 X 1 BOLTS**
- 4=5/16 X 1 1/4 BOLTS**
- 6=5/16 LOCK NUTS**
- 16=5/16 USS WASHERS**

IF THE WARN RT25 IS USED MUST USE THE METRIC BOLTS THAT ARE SUPPLIED WITH THE HARDWARE IN THE BAG WITH THE WINCH. THESE BOLTS ARE USED TO MOUNT THE WINCH TO THE PLATE.

IF THE HAWSE FAIRLEAD FROM WARN IS USED IN PLACE OF THE ROLLER FAIRLEAD USE THE BOLTS AND NUTS THAT OR ON THE HAWS.

298115-R95

KAWASAKI MULE 610 2X4 4X4

1ST STEP REMOVE THE FRONT PLASTIC BUMPER. THIS WILL BE REINSTALLED AFTER THE PLATE HAS BEEN MOUNTED.

2ND STEP DROP THE FRONT OF THE PLASTIC SKID PLATE AND PLACE THE SMALL PLATE WITH TWO HOLES IN BEHIND THE SQUARE HOLE AS SHOWN HERE.

3RD STEP MOUNT THE SUPPORT BRACKET TO THE SMALL BRACKET THAT WAS PLACED IN ON THE SECOND STEP. LEAVE ALL BOLTS LOOSE . USE TWO OF THE 5/16 X 1 1/4" BOLTS 5/16 USS WASHERS AND TWO LOCK NUTS.

3RD STEP MOUNT THE MAIN WINCH PLATE WITH 1/4 X 3/4 U-BOLTS 1/4 LOCK NUTS AND 1/4 USS WASHERS.

4TH STEP JUST MOUNT THE FRONT ROLLER FAIR LEAD HOLDER ON THE MAIN PLATE, USE FOUR OF THE 5/16 X 1 BOLTS 5/16 LOCK NUTS AND EIGHT OF THE 5/16 USS WASHERS. THIS PLATE ROTATE TO FIT LARGER SIZE WINCHES.

THIS IS JUST A PIC OF THE PLATE FROM A BOTTOM ANGLE. THE WINCH WILL BOLT USING TWO OF THE 5/16 X 1 BOLTS AND TWO OF THE 5/16 X 1 1/4 BOLTS AND FOUR 5/16 USS WASHERS. THE LONGER BOLTS WILL BE USED TO MOUNT THROUGH THE TWO PLATES INTO THE WINCH.(FRONT OF PLATE) REMEMBER TO TIGHTEN ALL BOLTS WHEN ALL PLATES HAVE BEEN MOUNTED.

