

4=1/4 X 3/4 U-BOLTS
8=1/4 LOCK NUTS
8=1/4 USS WASHERS



#298136-R116

2008 KAWASAKI BRUTE FORCE 750 4X4I

INSERT THE PLATE FROM ONE SIDE THEN COME IN WITH THE WINCH FROM THE OTHER SIDE. THEN SIT THE PLATE ONTO THE FRAME AND INSTALL THE U-BOLTS WITH THE WASHERS AND 1/4 LOCK NUTS.



THE MOUNTING OF THE WINCH AND PLATE IS MUCH EASIER IF THE FRONT OF THE BOTTOM SKID IS DROPPED.

