

2=1/4 X 3/4 U-BOLTS
2=1/4 X 1 U-BOLTS
8=1/4 USS WASHERS
8=1/4 LOCK NUTS



298141-R122

SUZUKI KING QUAD 400 4X4

INSERT THE PLATE FROM THE SIDE UNDER THE HEAD LIGHT. ANY SIDE WILL WORK.

MOUNT THE FRONT OF THE PLATE WITH THE TWO 1/4 X 1 U-BOLTS 1/4 USS WASHERS AND 1/4 LOCK NUTS.



MOUNT THE REAR OF THE PLATE ON TOP OF THE FRAME TUBE WITH THE TWO 1/4 X 3/4 U-BOLTS 1/4 USS WASHERS AND 1/4 LOCK NUTS.



MOUNT THE PLATE TO THE FRAME THEN INSTALL THE WINCH TO THE PLATE.