

- 2=1/4X3/8 U-BOLTS-A
- 4=1/4 LOCK NUTS-B
- 4=1/4 SAE WASHERS-C
- 2=5/16X1 BOLTS-D
- 2=5/16 LOCK NUTS-E
- 4=5/16 USS WASHERS (GR-5)-F



# #298146-R127

HONDA FOREMAN 500 2012

## 2000-2500LB WINCHES ONLY

THE EASIEST WAY TO MOUNT THE WINCH MOUNT PLATE TO THE FRAME. FIRST REMOVE THE PLASTIC FRONT BUMPER GUARD AND DROP THE FRONT OF THE BOTTOM SKID. PLACE THE PLATE INTO THE CAVITY PLACE HARDWARE INTO THE CORRECT LOCATIONS ON THE PLATE. DO NOT TIGHTEN ANY HARDWARE YET. SLIDE THE WINCH INTO THE FRONT CAVITY ALSO SCREW THE WINCH TO THE PLATE USING THE HARDWARE THAT COMES WITH THE WINCH. LEAVE ALL HARDWARE LOOSE. ONCE THE WINCH IS IN PLACE TIGHTEN ALL HARDWARE AND INSTALL THE ROLLER FAIRLEAD. THEN PROCEED TO REINSTALL THE SKID AND BUMPER GUARD.

