


- A = 2 = 5/16 x 2 3/4 Bolt
- B = 2 = 5/16 x 2 Bolts
- C = 8 = 5/16 Small Flat Washer (Sae.)
- D = 8 = 5/16 Locknut
- E = 4 = 1/4 x 1/2 U Bolt
- F = 2 = 1" Plugs
- G = 8 = 1/4 Sea. Flat Washer
- H = 8 = 1/4 Locknut
- . 1 = 529-BRK (Pair a right & left)
- . 2 = 3/16 x 1 1/4 Flat Bar x 2 1/2" Long with .

4=5/16 X 1 BOLTS
8=5/16 USS WASHERS



ON SOME OF THE NEW MODELS OF POLARIS THEIR WILL BE A SQUARE CHANNEL ON THE REAR RACK SUPPORT. IF YOUR BIKE HAS THIS USE THE 4=5/16 X 1 BOLTS AND THE 4=5/16 LOCK NUTS ALSO THE 8=5/16 USS LARGE WASHERS.

BOLT IN THESE HOLES IF YOU HAVE THE CHANNEL TYPE SUPPORTS.

This rear rack fits on top of the original rack and bolts up to the front an to the back bar that are going downward to the frame.