

- 2=1/4 LOCK NUTS-A
- 6=3/16 X 1 X 3/16 THICK WASHERS-B
- 40=1/4 X 1 TORX SCREWS-C
- 4=1/4 X 1 1/4 TORX SCREWS-D



# # SP122-AL

## COMPLETE FULL BODY SKIDS POLARIS 800 RZR

TO INSTALL THESE SCREWS (D)  
YOU WILL HAVE TO DRILL A  
7/32 HOLE FOR THE SCREWS.  
DRILL INTO THE FRAME  
WHEREVER THE  
COUNTERSINK HOLES ARE  
AFTER INSTALLING ALL SKIDS  
WITH THE ORIGINAL BOLTS  
AND WASHERS THAT WERE  
REMOVED FROM THE PLASTIC  
SKID PLATE.

1ST STEP MUST REMOVE THE  
LARGE PLASTIC SKID AND REUSE  
THE SCREWS WITH THE BELIEVED  
WASHERS. INSTALL THE TOP SKID  
FIRST LEAVE ALL SCREWS LOOSE  
UNTIL ALL SKIDS HAVE BEEN  
INSTALLED.





2ND STEP INSTALL THE BOTTOM  
PART OF THE SKID AND ALSO  
REUSE SOME OF THE STOCK  
SCREWS AND WASHERS THAT  
WERE REMOVED.

**USE PROPER LIFTING  
EQUIPMENT WHEN  
LIFTING THE  
MACHINE.**

IF OVER SIZED TIRES ARE USED  
YOU MAY HAVE TO REMOVE  
THE SMALL POCKET COVERS.

DRILL THROUGH THE PLASTIC AND USE  
THE 1/4" LOCK NUT ON THE INSIDE OF  
FLOORBOARD ON TOP OF A 1" WASHER.

USE TWO 3/16 X 1" WASHERS TO SPACE  
THE GUARDS FROM THE FRAME AND  
PLASTIC .



3RD STEP INSTALL THE LEFT SIDE SKID USE THE  
ORIGINAL FOUR SCREWS TO SECURE THE PLASTIC SIDE  
PANEL AND USE THE 1" TORX FOR THE REST OF THE SKID.

4TH STEP INSTALL THE RIGHT SIDE SKID USE THE  
ORIGINAL FOUR SCREWS TO SECURE THE PLASTIC SIDE  
PANEL AND USE THE 1" TORX FOR THE REST OF THE SKID.

